

MTP850 S User Guide



Volume control /
press+hold: lock / unlock volume control

LED
green = in use
green blinking = in service / on
red = out of range
red blinking = connecting to
network

Speaker

Push-to-talk (PTT)

Channel / Talk group

Optns / Select key

Power on / off

Arrow keys

Lock / Unlock keyboard

To change folder / talkgroup

- Press 'Optns'
- Select folder by pressing 'Select'
- Scroll to your chosen folder using the LEFT and RIGHT arrow keys
- Press 'Select' again

To change mode:

- Press 'Optns'
- Use DOWN arrow key to scroll to 'Direct Mode' or 'Trunked Mode'
- Press 'Select' again

R||RIEDEL